

The Compact Quadrifilar Antenna (CQA) for Handheld GPS and Satellite Radio Reception

Stanislav Licul, Jeremy Marks, Warren L. Stutzman Maxtena, Inc.

Antenna Systems Conference Denver, Colorado September 26-27, 2007



Outline

- Maxtena Overview
- Maxtena Technology and IP
- Why Differential?
- Antenna Geometry
- Phase Shifter
- Antenna Impedance and Tuning
- Differential GPS Antenna Performance
- Conclusions



Maxtena Overview

- Maxtena is a start-up company (founded in 2006)
- Focused on advance differential material technology
- GPS and cellular market
- Initial Product: GPS quadrifilar antenna using advance material differential technology



MAXTENA Maxtena Technology and IP

- Patent pending (Filed in 2006)
- New approach in antenna design using differential interface and advance materials
- Improved radiation characteristics
- More bandwidth!/Differential Feeding!/More Efficiency!/Smaller Size!
- Maxtena IP provides a unique platform for smaller and more efficient quadrifilar antennas



Why Differential?

RadioMax TM differential architecture with advance materials improves performance and integration capability



- Lower System BOM
- Smaller Size
- Minimizing Hand Detuning Effects
- Differential RFIC



MAXTENA Differential GPS Antenna – M1575CQA

•Frequency: 1575.42 MHz ±10MHz

Polarization: RHCP

•Efficiency: 38% (differential) -1.3 dBic

•Beamwidth: 140° (both axis)


•Axial Ratio: 0.2 dB (max)

•Front to back ratio: 12 dB

•VSWR: 1.3:1 (typical)

•Impedance: 100Ω (differential)

•Dimensions: 10mm diam. x 20mm length








MAXTENA Differential GPS Antenna M1575CQA

- Maxtena GPS quadrifilar antenna technology
 - Separate balun and symmetric antenna windings
 - Phase shifter board drives quadrature → simplifies antenna tuning
 - Excellent isolation between the ports, excellent amplitude and phase stability → better Circular Polarization
 - Differential interface reduces part count → more gain and efficiency
- Conventional GPS quadrifilar antenna technology
 - Integrated balun
 - Asymmetric (quadrature) antenna windings
 - Lower efficiency and gain
 - Lower Circular Polarization purity
 - Single-ended design



MAXTENA M1575CQA Geometry

L-shaped terminations and independent phase shifter board (single-ended or differential interface)





M1575CQA Phase Shifter

- Balun and two hybrid couplers using LTCC technology
- Three hybrid couplers using LTCC technology
- Able to achieve better than 20 dB isolation between the ports
- Phase balance +/- 3 degrees
- Amplitude balance +/- 0.5 dB


Maxtena, Inc. (SL)

September 2007




MAXTENA M1575CQA Phase Shifter

Typical Phase Shifter Topologies



Using three LTCC hybrid couplers

Using LTCC Balun and two hybrid couplers





M1575CQA Impedance and Tuning

General scattering matrix of a 4-port antenna

system:

$$S_{A} = \begin{bmatrix} s_{11} & s_{21} & s_{31} & s_{21} \\ s_{21} & s_{11} & s_{21} & s_{31} \\ s_{31} & s_{21} & s_{11} & s_{21} \\ s_{21} & s_{31} & s_{21} & s_{11} \end{bmatrix} \underbrace{\text{and}}_{A} a_{A} = S_{A}b_{A}.$$

• Ideal scattering matrix of a hybrid is:

$$S_H = \begin{bmatrix} 0 & 0.5 & -j0.5 & -0.5 & j0.5 \\ 0.5 & 0 & 0 & 0 & 0 \\ -j0.5 & 0 & 0 & 0 & 0 \\ -0.5 & 0 & 0 & 0 & 0 \\ j0.5 & 0 & 0 & 0 & 0 \end{bmatrix}$$



MAXTENA M1575CQA Impedance and Tuning

Reflection coefficient is the following:

$$\Gamma = s_{11} - s_{31}$$

- Parasitic impedance of the phase shifter board contributes to the antenna impedance
- Proper modeling required for optimal efficiency





MAXTENA M1575CQA Impedance and Tuning

- Antenna geometry (diameter, pitch angle, and height) optimized for specific desired impedance
- Impedance control through one stage matching required to match to desired phase shifter input impedance
- Maxtena developed a proprietary five-port tuning method
- The method simplifies tuning of the whole antenna system in one step process




M1575CQA Return Loss and Filtering









Contour Plot – Very Good Upper Hemisphere Symmetry











Elevation Patterns






^{*}Results shown with a balun (loss -1.1 dB)



RHCP vs. LHCP Rejection



Axial Ratio





Conclusions

- Advance Differential Material Technology
- Differential Interface
- Reduced BOM
- Increased Efficiency and Bandwidth
- Minimizing Hand Detuning Effects
- 7 mm design possible
- Technology applicable to cellular market for quad and penta-band antenna designs



Conclusions

Questions?

Comments?

Maxtena, Inc. (SL)

September 2007